

## オーディオ・ファイル再生時のご注意

MP3ファイルを再生したり、オーディオ・ファイルの再生テンポを変更したりしていると、RD-700GX／RD-300GXに大きな負荷がかかり、鍵盤からの演奏情報を処理しきれなくなることがあります。そのようなときは、以下の対処をすることで症状を改善できる場合があります。

- ・ MP3形式ではなく、WAV/AIFF形式のデータを使用する
- ・ 曲のテンポを元に戻す（0%にする）

MP3ファイルの先頭と最後にはわずかな空白があります。そのため、オーディオ・キー機能を使って繰り返し再生すると、音が途切れたように聞こえることがあります。そのようなときは、以下の対処をすることで症状を改善できる場合があります。

- ・ MP3形式ではなく、WAV/AIFF形式のデータを使用する



# Caution when Playing Back Audio Files

Playing back an MP3 file or changing the playback tempo of an audio file places a significant processing burden on the RD-700GX/RD-300GX, and in some cases may cause it to be unable to completely process all of the performance data from the keyboard.

If this occurs, you may be able to solve the problem by taking the following actions.

- Use WAV/AIFF format data rather than MP3 format data
- Return the song tempo to its original setting (to 0%)

An MP3 file has little time of the blank at the head and the end of the file. Therefore, the sound might cut off when an MP3 file played repeatedly with Audio Key function.

If this occurs, you may be able to solve the problem by taking the following actions.

- Use WAV/AIFF format data rather than MP3 format data

